


EASYMOVE 500 TROLLEY



MOTORISED TROLLEY FOR TRANSPORTING SHIELDED BINS

HIGH ENERGY



ASSOCIATED PRODUCTS

- Easydrop® 54 L HE bins
- Easydrop®+ 54 L HE bins

Easymove 500 is a **motorised trolley** equipped with a hydraulic pump actuator (drawbar) designed for the **removal and transport**, on smooth surfaces, of **high-energy shielded waste bins** used in **Nuclear Medicine** of the Lemer Pax or Medisystem brands: models **Easydrop® 54 L** and **Easydrop®+ 54 L**.



The Easymove 500 is **compact, lightweight, easy to use**, and ideal for **reducing** the operator **effort** required and increasing efficiency and safety, with a **maximum load** capacity of **500 kg**.

It is equipped with a **powerful** 36 V 12.8 Ah Li-Ion battery and a LED display that provides users with a variety of information as well as the ability to **adjust the** maximum travel **speed** from 3.2 to 5.3 km/h to suit specific applications. The trolley is **easily removable** and features an additional battery, for continuous operation.



Its **two large diameter** (200 mm) **drive wheels** offer **great stability** without the need for stabilisers. They are made of non-marking rubber, which provides excellent traction for an **extremely quiet** device. A switch allows to change from electric to manual mode in case of low battery. The trolley can then be used as a manual pallet truck. In order to move the unit in a narrow space, the trolley is equipped with a slow mode to allow operation with the drawbar in a vertical position at reduced speed.

CHARACTERISTICS

General

Overall length: 1,140 mm

Turning radius: 1,020 mm

Total width: 890 mm

Lifting: manual

Ground clearance in low position: 0 mm

Fork height: 125 mm

Driving system: assistance

Drawbar height in driving position:
710 mm min. / 1,185 mm max.

Travel speed with load:
4.2 km/h

Maximum slope under load: 5 %

Battery autonomy:
contact us

Battery voltage and capacity:
36 V-12.8 Ah

Noise level at operator's ear:
60 dB(A)

Nominal load capacity: 500 kg

Empty weight: 146 kg

Plate between forks:
L 600 x P 630 mm

Translation modes: electric strike plate

Lifting height: 115 mm

Fork width: 145 mm

Front wheels: 2 x Ø 200 x L 40 mm
Rubber

Rear wheels: 4 x Ø 200 x L 60 mm
Polypropylene

Travel speed without load: 5.3 km/h

Lowering speed with load: 0.1 m/s

Maximum slope when empty: 15 %

Service brake: electric latch plate

Battery weight: 3 kg

Ref.: 00040729